



Number	Name
01	Screw
01P	Allen Wrench
02	3/8" Chuck(for DR118-A1)
02P	Chuck Key(for DR118-A1)
03	Gear Housing
04	Washer
05	Ball Bearing
06	Planet Carrier
07A	Planet Gear(inc16)
08	Internal Gear
09	Ball Bearing
10	Bearing Case
11	Rear End Plate
12	Rotor
13	Rotor Blade
14	Motor Pin
15	Cylinder
16	Bushing
17	HANDLE W/SLEEVE
17A	HANDLE GRIP
20	Trigger
21	Valve Spring
22	Valve
22P	O-Ring
23	O-Ring
24	Reverse Valve
25	O-Ring
26	Reverse Valve Bushing
27	O-Ring
28	Pin

Number	Name
29	Exhaust Deflector
30	Screw
31	Inlet Bushing(PT19)
50	Trigger Plate
51	Spring
52	Valve Cap