



Number	Name
1	EXHAUST COVER
2	BOLT (M5x25L)
3	CAP
4	GASKET
5	HEAD VALVE SEAL A
6	CAP SPRING
7	CAP O-RING
8	HEAD VALVE O-RING
9	HEAD VALVE
10	HEAD VALVE SEAL O-RING
11	HEAD VALVE SEAL B
12	COLLAR
13	PISTON SET
13A	PISTON ASSEMBLY
14	PISTON O-RING
15	CYLINDER
16	CYLINDER O-RING
17	CYLINDER GUIDE
18	CYLINDER GUIDE O-RING
19	BUMPER
20	NOZZLE
21	BODY
22	END CAP O-RING
23	END CAP
24	AIR PLUG
25	PLUG CAP
26	GRIP
27	VALVE SET
28	VALVE PLUNGER O-RING
29	VALVE PLUNGER

Number	Name
30	PLUNGER SPRING
31	PLUNGER O-RING
32	PLUNGER
33	PLUNGER CAP O-RING
34	PLUNGER CAP
35	TRIGGER SPRING
36	PIN STOPPER O-RING
37	TRIGGER A(OUT)
38	PIN GUIDE
39	TRIGGER PIN
40	TRIGGER B (IN)
41	ROLL PIN (Φ3x14L)
42	BOLT (M5x22L)
43	GUIDE COVER A
44	CONTACT ARM
45	SAFETY LEVER
46	BOLT (M4x10L)
47	SAFETY GUIDE COVER
48	GUIDE COVER B
49	BOLT (M4x16L)
50	DRIVER GUIDE
51	STEEL PLATE
52	PUSHER
53	PUSHER SPRING
54	MAGAZINE A
55	MAGAZINE B
56	BOLT (M4x8L)
57	SPRING WASHER (for M4)
58	TWIN NUT
59	MAGAZINE END CAP

Number	Name
60	BUSHING
61	BOLT (M4x12L)
62	CLICK LEVER
63	CLICK LEVER SPRING
64	ROLL PIN (Φ3x18L)
65	BRACKET
66	BOLT (M5x12L)
68	BOLT (M4x6L)
69	LOCK NUT (for M5)
70	PUSHER HOLDER