



Number	Name
1	Housing Cover
2	Screw M3.5x15-L
3	Variable Speed Elastic Hardware
4	Variable Speed Knob
5	The Torque Elastic Hardware
6	F/R Lever
7	Chimney
8	Switch ASS'Y
9	Contact plate
10	Motor ASS'Y
11	Motor pad
12	Screws M5x25-L
13	keyless Drill Chuck
14	The Torque Cup
15	Internal Thread of The Torque Cup
16	Torque Spring
17	Flat Washer
18	Steel Ball R4.5MM
19	Two Speed Gear Box ASS'Y
20	The Adjusting Frame
21	Pin
22	Housing Support
23	Hasp
24	Charger
25	Battery
26	BMC