



RA-8016
Air Stapler

Number	Name
1	SCREW M4x18
2	WASHER4
3	Cylinder CAP
4	Trigger valve head
5	SEAL, AIR
6	O-RING 26.8x1.8
7	FEEDER SPRING
8	O-RING 11.8x2.4
9	FIRING VALVE PISTON
10	O-RING 26.6x2.4
11	O-RING 21.3x3
12	O-RING 8x3
13	O-RING 35x2
14	CYLINDER
15	BUMPER
16	GASKET
17	E-RING φ2.5
18	NOZZLE
19	SEAL,AIR T=2.5
20	Upper Housing
21	Remote Core
22	O-RING 3.5x1.5
23	TRIGGER VALVE GUIDE
24	O-RING 11x1.9
25	TRIGGER
26	Body
27	GASKET
28	Tail Cover
29	Silencer
30	SPRING PIN 2.5x22
31	PIN
32	CLICK LEVER B

Number	Name
33	FEEDER SPRING
34	PIN
35	CLICK LEVER A
36	AIR PLUG
37	DRIVER GUIDE
38	SPACER
39	UPPER MAG
40	SPRING PIN 2.5x11
41	FRONT PART
42	Wheel guide
43	Guide Plate
44	NAIL TANK
45	Pusher
46	FEEDER SPRING
47	SCREW M4x10
48	SPRING PIN 2.5x28
49	Tail Cover
50	O-RING 17.8x2.8
51	PIN 4.2x13.5
52	Piston head
53	DRIVER BLADE
54	LOWER MAGAZINE SET
55	PISTON SET
56	MAGAZINE SET
57	SPRING
58	LANTERN RING