



RC-0612

Silent Air Compressor 6L-6000W

Number	Name
1	Socket Cable
2	Cable Clip,Socket
3	Nut,Rubber Sustain,Tank
4	Rubber Sustain,Tank
5	Bolt,Rubber Sustain,Tank
6	Drain Valve
7	Air Tank
8	Released Bracket
9	Ball Valve
10	Pressured Guage
11	Safety Valve
12	Elbow
13	Nut,Solenoid valves
14	Solenoid valves
15	Single Way Valve
16	Pressured Pipe
17	Wiring Terminal
18	Capacitance
19	Nut,Capacitance Box
20	Capacitance Box
21	Wiring,Switch-1
22	Wiring,Switch-2
23	Wiring,Switch-3
24	Screw,Capacitance Box
25	Bolt,Capacitance Box
26	Power Switch
27	Pressure Sensor
28	Rubber Foot,Head
29	Nut,Rubber Foot,Head
30	Crankcase,Right
31	Bearing,6005
32	Cramshaft
33	Fan
34	Fan Clip
35	Fan Cover
36	Screw,Fan Cover
37	Bolt,Stator
38	Rotor
39	Stator
40	6301 Bearing
41	Crankcase,Left
42	Bolt,Rod
43	Rod
44	Sealing Cup
45	Pressured Plate
46	Bolt,Pressured Plate
47	Cylinder
48	Screw,Valve Disc
49	Intake Plate,Valve Disc
50	Sealing,Valve Plate

Number	Name
51	Valve Plate
52	Valve Disc
53	Limited Block
54	sealing,Cylinder Head
55	Cylinder Head,Left
56	Spring Washer,Cylinder Head
57	Bolt,Cylinder Head
58	Cover,Cylinder Head
59	Bolt,Handle
60	Handle
61	Screw,Muffler
62	Pipe,Cylinder Head
63	Cylinder Head,Right
64	Sponge-A,Muffler
65	Sponge-B,Muffler
66	Sealing,Pipe,Muffler Box
67	Muffler Box