



RS-8018

Cordless impact drill driver kit

| Number | Name |
|--------|-----------------------------|
| 1 | screw |
| 2 | chuck |
| 3 | Tachometer adjustment frame |
| 24 | Mode change slider |
| 30 | screw |
| 34 | screw |
| 38 | The key to change the mode |
| 40 | spring belt |
| 41 | Left and right key |
| 43 | inductance |
| 46 | battery (Small Socket) |
| 47 | charger (Large Socket) |
| 47 | charger (Small Socket) |
| 48 | switch |
| 60 | gearbox |
| 61 | Motor+gear |
| 62 | Speed control button |
| 63 | right/left housing |